

## THERMOMETERS

The movement used in this dial type thermometer is constructed of precision components, and will only need to be adjusted under extraordinary circumstances. Should the need occur, however, the indicator hand can be adjusted to the correct reading by following these steps:

- 1) Insert a small screwdriver into the hole in the back of the movement housing, and into the slot on the top of the thermometer coil mounting bracket.
- 2) Slowly turn the mounting bracket, being careful not to touch the coil. Turning the bracket to one side will increase the needle reading, while turning to the other side will decrease the needle reading.

**Weems & Plath<sup>®</sup>**

214 EASTERN AVE. • ANNAPOLIS, MD 21403 • USA  
410-263-6700 • fax 410-268-8713 • [www.weems-plath.com](http://www.weems-plath.com)

E-mail: [support@weems-plath.com](mailto:support@weems-plath.com)

1/03